



Sold at Target Australia stores and online from 30 January 2021 to 5 October 2022

Defect: The stool legs are not strong enough and may collapse when weight is applied.

Hazard: If the stool collapses the user may be seriously injured.

What to do: Consumers should immediately cease using the stool, safely dismantle it and dispose of it securely.

To obtain a full refund, photographic evidence of the dismantled stool and its disposal will be required. Please send your photographs to TargetRecalls@target.com.au

Consumers can also choose to return the stool to the nearest Target store, for a full refund.

Contact Details: For further information, phone Target Customer Support Centre on 1300 753 567 (M-F 9.00am-7.00pm AEST; Saturday 9.00am-5.00pm AEST) or visit https://www.target.com.au/contact-us

See productsafety.gov.au for Australian product recall information